

NOTE.

The remote control handset has a set of unique ID codes that are pre-programmed into its memory; therefore the remote control must be matched to the control box. THIS MUST BE CARRIED OUT BEFORE OPERATING THE GAS FIRE. The instructions are included with the remote control. This means that the control box will only respond to the appropriate remote control handset.

The Remote Control Handset has a unique ID code that is pre-programmed into its memory. This set of ID codes helps to differentiate one handset to another. To match the remote to the control box, the following steps are required.

1. Turn off main power to heater (*FireGenie*) Or slide remote receiver to “OFF” position (*Advanced remote*)
2. Remove battery from remote hand set
3. Turn main power on to the heater (*FireGenie*) or slide remote receiver to “REMOTE” position. (*Advanced remote*)
4. Re-fit battery into remote handset
5. Press and hold the *PROG* and *FAN (FireGenie)* or *PROG* and *PRESET (Advanced remote)* buttons simultaneously. The screen display will show the letters “LC” momentarily indicating the ID codes have been transmitted.
6. Release both the *PROG* and *FAN* buttons, the display will revert back to the normal off mode display
7. Turn remote to on, unit should now operate

NOTE: The control box will only learn the remote ID code during the first 30 seconds after the power is turned on to the heater